



Release Notes: F-950

Version 1.7.5.8

Release Date: April 3, 2017

Changes

- Trigger mode volume drawn is capped at 60 mL
-

Version 1.7.5.7

Release Date: October 12, 2015

Fixes

- Fixes bug where unit would throw sensor error when unit is not warmed up

Changes

- New splash screen
- Other interface enhancements
- Internal calibration procedure for the CO2 sensor

Additions

- User gets warning when the CO2 concentration is out of range (greater than 20%)
 - Spanish and Portuguese language added.
-

Version 1.6.7

Release Date: August 21, 2015

Fixes

- CO2 measurements higher than 20% no longer predicts zero.
- GPS shuts down properly to preserve battery.

Additions

- User is prompted to shut down device to prevent loss of data
- Factory Settings: Backup and Restore to SD card
- Other interface enhancements



- Firmware “remembers” the last file opened
-

Version: 1.5.3

Release Date: July 2, 2015

Additions

- Enables the GPS in the device. Can be enabled by navigating to Setup>GPS
- Raw ADC counts added to data output

Fixes

- Fixes a bug where oxygen sensor reads 100% when pure nitrogen passes through the unit
-

Version 1.4.7

Release Date: June 19, 2015

Changes

- The CO₂ sensor is no longer zeroed during the set zero routine
 - The sensors can be individually zeroed rather than all three at the same time
-

Version 1.4.5

Release Date: May 12, 2015

Fixes

- Fixes minor bugs
 - CO₂ sensor improvements in monitor mode
-

Version 1.4.2

Release Date: April 24, 2015



Changes

- implements an improved humidity correction on the C₂H₄ sensor
-

Version 1.3.0.12

Release Date: February 16, 2015

Changes

- Longer threshold when detecting clog to prevent false positives
 - C₂H₄ peak adjustment due to gas consumption rate during fixed volume mode.
-

Version 1.3.0.8

Release Date: January 23, 2015

Changes

- "Trigger Mode" improvements
- Improved offset algorithm
- The temperature compensation algorithm was improved for the CO₂ sensor