



Release Notes: F-900

Version 4.6.1

Release Date: August 21, 2015

Changes

- The connection menu has been removed from setup menu. It is no longer necessary.
- The Temperature and RH parameters are automatically populated during C₂H₄ ppb sensor span.

Fixes

- Cleaning signal is ignored during offset correction
- CO₂ GC emulation is improved by flushing between samples prompted by software. This is for the % CO₂ sensor.
- % CO₂ sensor calibration/parameters fix for concentrations greater than 20%

Additions

- C₂H₄ ppb sensor manual calibration routine added using demand flow regulator. To access this routine, navigate to: Setup > Calibration > C₂H₄ > PPB > Re-calibration
-

Version: 4.5.26

Release Date: July 2, 2015

Additions

- Terminal Block: pin 6 alerts the user of low battery, flow blocked, or measurement out of range
- Set zero (settings menu while in monitor mode): A stability check is added to this feature by checking that the signal does not change more than 40 ppb for a period of 10 minutes. The user is also asked to confirm whether KMnO₄ is present in the solids chamber before beginning the “Set Zero” routine.

Fixes

- Improved accuracy of CO₂ and O₂ measurements in GC Emulation mode



Changes

- Terminal Block: pin 5 is changed from “fan” to “measure ready”
-

Version 4.5.18

Release Date: June 11, 2015

Fixes

- Improves the accuracy of the CO₂ sensor “Monitor” mode
-

Version 4.5.2

Release Date: February 26, 2015

Additions

- **Enable USB connection in HID mode**
-

Version 4.5.0

Release Date: January 23, 2015

Fixes

- Firmware bug where the gas valve and fan were turning on and off at the same time regardless of the threshold set on the setup menu; this is when using the terminal block
-