



Release Notes: F-920

Version 1.9.5.8

Release Date: December 4, 2017

Additions

- The user is warned if the flow is blocked and the pump is shut off

Changes

- Bug fixes
- Addresses a bug, where the countdown timer displayed while setting the zero for CO₂ shows a negative number
- Addresses an issue where at ambient it read 99% for O₂ and/or CO₂

Version 1.9.5.4

Release Date: August 9, 2017

Additions

- Support for screen capture using G.A.S software

Changes

- Bug fixes

Version 1.9.4.1

Release Date: March 12, 2017

Additions

- Passcode to enter calibration menu enabled (SETUP>CALIBRATION) as well as the Set Zero menu (SETUP>SET ZERO).

Changes

- Menus related to calibration got rearranged

Fixes

- Improved accuracy of O₂ at low concentrations
- Reduced variability of volume drawn in Trigger mode



Version 1.9.3.3

Release Date: March 7, 2017
