



Release Notes: F-960

Version 1.9.5.4

Release Date: August 9, 2017

Additions

- Support for screen capture using G.A.S software

Changes

- External KMNO₄ chamber required during a “Set Zero” procedure (does not use internal chamber)
- Set zero now takes 600 seconds (previously it was 300)
- Bug fixes

Version 1.9.4.1

Release Date: March 12, 2017

Additions

- Passcode to enter calibration menu enabled (SETUP>CALIBRATION) as well as the Set Zero menu (SETUP>SET ZERO).

Changes

- Menus related to calibration got rearranged
- User is warned when the C₂H₄ concentration is above 1000 ppm (displays “out of range” message on the bottom right of screen in continuous mode)

Fixes

- Fixed bug of Ethylene decimal places in Continuous mode

Version 1.9.3.5
